

**max. 3 mellék
minden videó (audió) LC-hez**



Színválaszték:
 .1 óarany
 .2 óezüst
 .5 inox

DC
elektromos zár

Tápegység
4FP 672 59

230V/50Hz

A vintage Sony CCD camera with a color LCD screen. The screen displays a woman with dark hair and bangs, wearing a red turtleneck sweater, smiling. The background in the video feed shows a brick house and a metal fence. Below the screen is a control panel with a row of buttons labeled DEL, SET, F.W, BW, REC, and CAM, each with a number from 1 to 6. Below these buttons is a large circular dial with a key symbol in the center and four directional arrows (up, down, left, right) around it. To the left of the dial is a grid of small buttons. At the bottom of the camera are several icons: a battery level indicator, a speaker icon, a power icon, and a small circular icon with a dot in the center.

max. 3 mellék LC

FLC1 MLC1, MLC2, MLC3
4FP 110 83, 4FP 211 03
4FP 211 23, 4FP 211 42

Pótcsenő LC-hez
4 FN 605 22 (műanyag)
4 FN 605 26 (kerámia)

max. 8 db EV
(1 fő kapuk. (FEV)+7 mellék kapuk. (MEV))

Mellék kapu MEV

Mellé

audió kapu EV

Elektromos zár
4 FN 877 11

GUARD 2-BUS tasztatúra hívóművel

Tápegység
4 FP 672 57 (max.1

230V/50Hz

* Ha a tápfeszültség (+18V és GND pontok között) 14 V alá csökken (működés közben) a rendszer működéseképtelené válhat. (A rendszer felszerelése után méréssel ellenőrizni.)
Ilyen esetekben szükség lehet több ponton megtáplálni a rendszert. Audió, illetve Videó rendszer függvényében válaszuk ki a további tápegység típusát. (audió: 4 FP 672 57, videó: 4 FP 672 59)